



L89 GNSS

Protocol Specification

GNSS Module Series

Rev. L89_GNSS_Protocol_Specification_V1.0

Date: 2019-04-16

Status: Released

Our aim is to provide customers with timely and comprehensive service. For any assistance, please contact our company headquarters:

Quectel Wireless Solutions Co., Ltd.

7th Floor, Hongye Building, No.1801 Hongmei Road, Xuhui District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: info@quectel.com

Or our local office. For more information, please visit:

<http://www.quectel.com/support/sales.htm>

For technical support, or to report documentation errors, please visit:

<http://www.quectel.com/support/technical.htm>

Or email to: support@quectel.com

GENERAL NOTES

QUECTEL OFFERS THE INFORMATION AS A SERVICE TO ITS CUSTOMERS. THE INFORMATION PROVIDED IS BASED UPON CUSTOMERS' REQUIREMENTS. QUECTEL MAKES EVERY EFFORT TO ENSURE THE QUALITY OF THE INFORMATION IT MAKES AVAILABLE. QUECTEL DOES NOT MAKE ANY WARRANTY AS TO THE INFORMATION CONTAINED HEREIN, AND DOES NOT ACCEPT ANY LIABILITY FOR ANY INJURY, LOSS OR DAMAGE OF ANY KIND INCURRED BY USE OF OR RELIANCE UPON THE INFORMATION. ALL INFORMATION SUPPLIED HEREIN IS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

COPYRIGHT

THE INFORMATION CONTAINED HERE IS PROPRIETARY TECHNICAL INFORMATION OF QUECTEL WIRELESS SOLUTIONS CO., LTD. TRANSMITTING, REPRODUCTION, DISSEMINATION AND EDITING OF THIS DOCUMENT AS WELL AS UTILIZATION OF THE CONTENT ARE FORBIDDEN WITHOUT PERMISSION. OFFENDERS WILL BE HELD LIABLE FOR PAYMENT OF DAMAGES. ALL RIGHTS ARE RESERVED IN THE EVENT OF A PATENT GRANT OR REGISTRATION OF A UTILITY MODEL OR DESIGN.

Copyright © Quectel Wireless Solutions Co., Ltd. 2019. All rights reserved.

About the Document

History

Revision	Date	Author	Description
1.0	2018-04-16	Jenn XIANG	Initial

Contents

About the Document	2
Contents	3
Table Index.....	5
1 Introduction	6
2 Commands.....	7
2.1. ST NMEA Commands List	7
2.2. ST NMEA Commands.....	8
2.2.1. \$PSTMINITGPS.....	8
2.2.2. \$PSTMINITTIME	9
2.2.3. \$PSTMCLREPHS	10
2.2.4. \$PSTMDDUMPEPHEMS	11
2.2.5. \$PSTMCLRALARMS	20
2.2.6. \$PSTMDDUMPALMANAC	21
2.2.7. \$PSTMCOLD	26
2.2.8. \$PSTMWARM	27
2.2.9. \$PSTMHOT	27
2.2.10. \$PSTMSRR.....	28
2.2.11. \$PSTMSBASONOFF	28
2.2.12. \$PSTMSBASSERVICE.....	28
2.2.13. \$PSTMGETRTCTIME	29
2.2.14. \$PSTMSETCONSTMASK	30
2.2.15. \$PSTMPPS	31
2.2.15.1. Getting PPS Data (cmd_mode=1).....	32
2.2.15.2. Setting PPS Data (cmd_mode=2)	36
2.2.16. \$PSTMFORCESTANDBY	41
2.2.17. \$PSTMGEOFENCEREQ	41
2.2.18. \$PSTMODOSTART	42
2.2.19. \$PSTMODOSTOP	42
2.2.20. \$PSTMODOREQ	43
2.2.21. \$PSTMCFGCONST	43
2.2.22. \$PSTMODORESET	44
2.2.23. \$PSTMCFGPORT	45
2.2.23.1. Parameters when port_type is UART	46
2.2.23.2. Parameters when port_type is I2C	46
2.2.24. \$PSTMCFGMSGSL	46
2.2.25. \$PSTMCFGAGPS.....	50
2.2.26. \$PSTMCFGAJM	50
2.2.27. \$PSTMCFGODO	51
2.2.28. \$PSTMCFGGEOFENCE	52
2.2.29. \$PSTMCFGGEOCIR	52

2.2.30. \$PSTMSETTHTRK	53
2.2.31. \$PSTMSETTHPOS	54
2.2.32. \$PSTMSETANTSENSOPMODE	54
2.2.33. \$PSTMSETANTSENSMANUAL	55
2.3. System Commands.....	56
2.3.1. \$PSTMSAVEPAR	56
2.3.2. \$PSTMRESTOREPAR.....	57
3 Messages	58
3.1. Standard NMEA Messages List	58
3.2. ST NMEA Messages List	58
3.3. Standard NMEA Messages Specification	58
3.3.1. \$--RMC	59
3.3.2. \$--VTG	61
3.3.3. \$--GGA	62
3.3.4. \$--GSA	64
3.3.5. \$--GSV	65
3.3.6. \$--GLL	67
3.4. ST NMEA Messages Specification	68
3.4.1. \$PSTMANTENNASTATUS	68
3.4.2. \$PSTMGEOFENCESTATUS	69
3.4.3. \$PSTMODO	69
4 Default Configurations	71
5 Appendix A References.....	72

Table Index

TABLE 1: ST NMEA COMMANDS LIST	7
TABLE 2: STRUCTURE OF STANDARD NMEA MESSAGES	59
TABLE 3: DEFAULT CONFIGURATIONS	71
TABLE 4: RELATED DOCUMENTS	72
TABLE 5: TERMS AND ABBREVIATIONS	72

1 Introduction

L89 GNSS module supports GPS, GLONASS, BeiDou, Galileo, QZSS and IRNSS constellations and features accurate acquisition. The module supports autonomous GNSS C/A and SBAS functions. It can be used in the positioning, navigation and other industries.

This document describes the software aspects of L89. L89 supports NMEA 0183 standard messages. ST NMEA extended commands are supported to control and configure L89 GNSS module.

2 Commands

2.1. ST NMEA Commands List

The table below summarizes all the commands supported by the ST NMEA layer.

Table 1: ST NMEA Commands List

Syntax	Description
\$PSTMINITGPS	Initialize GPS position and time
\$PSTMINITTIME	Initialize GPS time
\$PSTMCLREPHS	Clear all ephemeris
\$PSTMDUMPEPHEMS	Dump ephemeris data
\$PSTMCLRALMS	Clear all almanacs
\$PSTMDUMPALMANAC	Dump almanacs data
\$PSTMCOLD	Perform cold start
\$PSTMWARM	Perform warm start
\$PSTMHOT	Perform hot start
\$PSTMSRR	Reset system
\$PSTMSBASONOFF	Enable/disable SBAS activity
\$PSTMSBASSERVICE	Set SBAS service
\$PSTMGETRTCETIME	Get current RTC time
\$PSTMSETCONSTMASK	Set GNSS constellation mask
\$PSTMPPS	Manage command interface for pulse per second
\$PSTMFORCESTANDBY	Force the platform to enter into standby mode

\$PSTMGEOFENCEREQ	Request internal geo-fence subsystem status
\$PSTMODOSTART	Enable and reset odometer subsystem
\$PSTMODOSTOP	Stop odometer subsystem
\$PSTMODOREQ	Request odometer subsystem status
\$PSTMODORESET	Reset odometer subsystem
\$PSTMCFGCONST	Configure constellation
\$PSTMCFGPORT	Configure char port
\$PSTMCFGMSGList	Configure message list
\$PSTMCFGAGPS	Configure assisted GNSS
\$PSTMCFGAJM	Configure anti-jamming
\$PSTMCFGODO	Configure odometer
\$PSTMCFGGEOFENCE	Configure geo-fencing
\$PSTMCFGGEOCIR	Configure geo-fencing circle
\$PSTMSETTHTRK	Set track threshold
\$PSTMSETTHPOS	Set position threshold
\$PSTMSETANTSENSOPMODE	Set antenna sensing operating mode
\$PSTMSETANTSENSMANUAL	Control antenna state manually

2.2. ST NMEA Commands

2.2.1. \$PSTMINITGPS

The command initializes GPS position and time using UTC format. It must be issued after a cold reset or it fails. The date issued with parameters Day, Month and Year must be later than January 2018, and this threshold can be changed using the configuration options.

Synopsis:

```
$PSTMINITGPS,<Lat>,<LatRef>,<Lon>,<LonRef>,<Alt>,<Day>,<Month>,<Year>,<Hour>,<Minute>,<Second><cr><lf>
```

Arguments:

Parameter	Format	Description
Lat	DDMM.MMM	Latitude (degree – minute.minute decimals)
LatRef	'N' or 'S'	Latitude direction (north or south)
Lon	DDDMM.MMM	Longitude (degree – minute.minute decimals)
LonRef	'E' or 'W'	Longitude direction (east or west)
Alt	dddd – Decimal, 4 digits	Altitude in meters (-1500 to 100000)
Day	dd – Decimal, 2 digits	Day of month (01 to 31)
Month	mm – Decimal, 2 digits	Month (01 to 12)
Year	YYYY – Decimal, 4 digits	Year (2018 - ...)
Hour	HH – Decimal, 2 digits	Hour (00 to 23)
Minute	MM – Decimal, 2 digits	Minute (00 to 59)
Second	SS – Decimal, 2 digits	Second (00 to 59)

Results:

- The position and time will be initialized.
- The following message will be output on NMEA communication channel:

\$PSTMINITGPSOK<cr><lf>	If successfully initialized the GPS position and time.
\$PSTMINITGPSERROR<cr><lf>	If failed to initialize the GPS position and time.

Example:

\$PSTMINITGPS,4811.365,N,01164.123,E,0530,23,02,2018,09,44,12

2.2.2. \$PSTMINITTIME

The command initializes GPS time using UTC format. The date issued with parameters Day, Month and Year must be later than January 2018, and this threshold can be changed using the configuration options.

Synopsis:

\$PSTMINITTIME,<Day>,<Month>,<Year>,<Hour>,<Minute>,<Second><cr><lf>
--

Arguments:

Parameter	Format	Description
Day	dd – Decimal, 2 digits	Day of month (01 to 31)
Month	mm – Decimal, 2 digits	Month (01 to 12)
Year	YYYY – Decimal, 4 digits	Year (2018 - ...)
Hour	HH – Decimal, 2 digits	Hour (00 to 23)
Minute	MM – Decimal, 2 digits	Minute (00 to 59)
Second	SS – Decimal, 2 digits	Second (00 to 59)

Results:

- The time will be initialized.
- The following message will be output on NMEA communication channel:

\$PSTMINITTIMEOK<cr><lf>	If successfully initialized the GPS time.
\$PSTMINITTIMEERROR<cr><lf>	If failed to initialize the GPS time.

Example:

\$PSTMINITTIME,23,02,2018,09,44,12

2.2.3. \$PSTMCLREPHS

The command clears all ephemeris, which is stored in the NVM backup memory.

Synopsis:

\$PSTMCLREPHS<cr><lf>

Arguments:

None.

Results

- All ephemeris, stored in the non-volatile backup memory (either Backup-SRAM or Flash), will be deleted.
- No message will be sent as reply.

Example:

\$PSTMCLREPHS

2.2.4. \$PSTMDUMPEPHEMS

The command sends out all ephemeris stored in the backup memory.

Synopsis:

```
$PSTMDUMPEPHEMS<cr><lf>
```

Arguments:

None.

Results

```
$PSTM Ephem,<sat_id>,<N>,<byte1>,...,<byteN>*<checksum><cr><lf>
```

Where:

Parameter	Format	Description
sat_id	Decimal, 2 digits	Satellite number
N	Decimal, 1 digit	Number of the ephemeris data bytes
byte1	Hexadecimal, 2 digits	First byte of the ephemeris data
byteN	Hexadecimal, 2 digits	Last byte of the ephemeris data
checksum	Hexadecimal, 2 digits	Checksum of the message bytes without *<checksum><cr><lf> characters.

The N Bytes that are in the message are the dump of a structures that contain all the information of the ephemeris. Data are stored in this structure according to the following table if the data are for GPS:

Bits	Structure Member	Description
16	week	Week number of the issue of data
16	toe	Time of week for ephemeris epoch
16	toc	Time of week for clock epoch
8	iode1	Issue of data 1
8	iode2	Issue of data 2
10	iodc	Issue of data clock
14	i_dot	Rate of inclination angle
8	reserved	

24	omega_dot	Rate of right ascension
8	reserved	Must be 0
16	crs	Amplitude of the sine harmonic correction to the orbit radius
16	crc	Amplitude of the cosine harmonic correction to the orbit radius
16	cus	Amplitude of the sine harmonic correction to the argument of latitude
16	cuc	Amplitude of the cosine harmonic correction to the argument of latitude
16	cis	Amplitude of the sine harmonic correction to the angle of inclination
16	cic	Amplitude of the cosine harmonic correction to the angle of inclination
16	motion_difference	Mean motion difference from computed value
16	reserved	Must be 0
32	inclination	Inclination angle at reference time
32	e	Eccentricity
32	root_A	Square root of major axis
32	mean_anomaly	Mean anomaly at reference time
32	omega_zero	Longitude of ascending node of orbit plane at weekly epoch
32	perigee	Argument of perigee
8	time_group_delay	Estimated group delay differential
8	af2	Second order clock correction
16	af1	First order clock correction
22	af0	Constant clock correction
1	reserved	Reserved for use by GNSS library – must be 1
1	reserved	Reserved for use by GNSS library – must be 1
1	reserved	Reserved for use by GNSS library – must be 1
1	available	Contains 1 if ephemeris is available, 0 if not
1	health	Contains 1 if the satellite is unhealthy, 0 if healthy

1	reserved	Must be 0
4	accuracy	Accuracy

For GLONASS, the table is:

Bits	Structure Member	Description
16	week	Week number of the issue of data
16	toe	Time of week for ephemeris epoch
4	toe_lsb	Time of week for ephemeris epoch (LBS)
11	NA	Calendar day number within the four-year period since the beginning of last leap year (almanac)
7	tb	Time of ephemeris index
2	M	Type of satellite 00=GLONASS 01=GLONASS-M
2	P1	Time interval between two adjacent tb parameters
1	P3	Number of satellites for which almanac is transmitted within this frame 0=4 1=5
1	P2	Flag of oddness ("1") or evenness ("0") of the value of tb
1	P4	Flag to show that ephemeris parameters are present
1	KP	Notification on forthcoming leap second correction of UTC
1	reserved	
27	xn	Satellite PZ-90 x coordinate at epoch tb
5	xn_dot_dot	Satellite PZ-90 x velocity at epoch tb
24	xn_dot	Satellite PZ-90 x acceleration component at epoch tb
5	n	Slot number (1...24)
3	Bn	Healthy flags
27	yn	Satellite PZ-90 y coordinate at epoch tb
5	yn_dot_dot	Satellite PZ-90 y acceleration component at epoch tb

24	yn_dot	Satellite PZ-90 y velocity at epoch tb
8	age_h	Age of predicted ephemeris (hours)
27	zn	Satellite PZ-90 z coordinate at epoch tb
5	zn_dot_dot	Satellite PZ-90 z acceleration component at epoch tb
24	zn_dot	Satellite PZ-90 z velocity at epoch tb
8	reserved	Must be 0
11	gamma_n	Satellite clock frequency drift at epoch tb
5	E_n	Age of the ephemeris information
4	freq_id	Frequency ID
12	reversed	
22	tau_n	Satellite clock correction at epoch tb
10	reserved	Must be 0
32	tau_c	GLONASS to UTC(SU) time correction
22	tau_GPS	GLONASS to GPS system time correction
10	reserved	
11	NT	Calendar day number of ephemeris within the four-year period since the beginning of last leap year
5	N4	Four-year interval number starting from 1996
12	tk	Satellite time referenced to the beginning of the frame
4	FT	Predicted satellite user range accuracy at time tb
32	reserved	
5	m_available	Must be 0x1F
1	nvm_reliable	Must be 1
26	spare	
25	reserved	
1	available	Contains 1 if ephemeris is available, 0 if not

1	health	Contains 1 if the satellite is unhealthy, 0 if healthy
1	reserved	Must be 0
4	reserved	

For Galileo, the data are decoded according to the following table:

Bits	Structure Member	Description
16	week	Week number of the issue of data
16	toe	Time of week for ephemeris epoch
2	reserved	
16	toc	Time of week for clock epoch
10	iod_nav	Issue of data
8	SISA	Signal in space accuracy
10	reserved	Must be 0
10	BGD_E1_E5a	E1-E5a broadcast group delay
10	BGD_E1_E5b	E1-E5b broadcast group delay
2	E1BHS	E1-B signal health status
32	inclination	Inclination angle at reference time
32	eccentricity	Eccentricity
32	root_a	Square root of major axis
32	mean_anomaly	Mean anomaly at reference time
32	omega_zero	Longitude of ascending node of orbit plane at weekly epoch
32	perigee	Argument of perigee
14	i_dot	Rate of inclination angle
1	available	Contains 1 if ephemeris is available, 0 if not
1	health	Contains 1 if the satellite is unhealthy, 0 if healthy
16	motion_difference	Mean motion difference from computed value

16	crs	Amplitude of the sine harmonic correction to the orbit radius
16	crc	Amplitude of the cosine harmonic correction to the orbit radius
16	cus	Amplitude of the sine harmonic correction to the argument of latitude
16	cuc	Amplitude of the cosine harmonic correction to the argument of latitude
16	cis	Amplitude of the sine harmonic correction to the angle of inclination
16	cic	Amplitude of the cosine harmonic correction to the angle of inclination
24	omega_dot	Rate of right ascension
6	SVID	Satellite identification
1	E1BDVS	E1-B data validity status
1	reserved	Must be 0
8	reserved	Must be 0
16	reserved	Must be 0
6	af2	Second order clock correction
21	af1	First order clock correction
5	word_available	Must be 0x1F
31	af0	Constant clock correction
1	reserved	
6	reserved	Must be 0
26	reserved	Reserved for use by GNSS library – must be 1
1	reserved	Must be 0

For BeiDou:

Bits	Structure Member	Description
32	inclination	Inclination angle at reference time
32	eccentricity	Eccentricity

32	root_a	Square root of major axis
32	mean_anomaly	Mean anomaly at reference time
32	omega_zero	Longitude of ascending node of orbit plane at weekly epoch
32	perigee	Argument of perigee
17	toe	Time of week for ephemeris epoch
10	time_group_delay	Estimated group delay differential
5	aode	Issue of data, ephemeris
24	omega_dot	Rate of right ascension
8	A0	Ionospheric delay model parameter α_0
24	af0	Constant clock correction
8	A1	Ionospheric delay model parameter α_1
20	sow	Seconds of week
11	af2	Second order clock correction.
1	is_geo	1 for geostationary satellites, otherwise 0
22	af1	First order clock correction
10	subframe_avail	Must be 0x3FF
16	motion_difference	Mean motion difference from computed value
8	A2	Ionospheric delay model parameter α_2
8	A3	Ionospheric delay model parameter α_3
18	crs	Amplitude of the sine harmonic correction to the orbit radius
8	B2	Ionospheric delay model parameter β_2
4	urai	User range accuracy index
2	reserved	Must be 0
18	crc	Amplitude of the cosine harmonic correction to the orbit radius
8	B3	Ionospheric delay model parameter β_3

5	aodc	Issue of data, clock
1	spare	
18	cus	Amplitude of the sine harmonic correction to the argument of latitude
14	i_dot	Rate of inclination angle
18	cuc	Amplitude of the cosine harmonic correction to the argument of latitude
8	B0	Ionospheric delay model parameter β_0
6	spare	
18	cis	Amplitude of the sine harmonic correction to the angle of inclination
8	B1	Ionospheric delay model parameter β_1
6	reserved	Must be 0
18	cic	Amplitude of the cosine harmonic correction to the angle of inclination
1	nvm_reliable	Must be 1
11	reserved	Must be 0
2	spare	
17	toc	Time of week for clock epoch
13	week	Week number of the issue of data
1	available	Contains 1 if ephemeris is available, 0 if not
1	health	Contains 1 if the satellite is unhealthy, 0 if healthy

For IRNSS:

Bits	Structure Member	Description
16	toe	Ephemeris reference time
16	toc	Time of clock
32	mean_anomaly	Mean anomaly at reference time
32	eccentricity	Eccentricity
32	root_a	Square root of the semi-major axis

32	omega_zero	Longitude of ascending node of orbit plane at weekly epoch
32	perigee	Argument of perigee
32	inclination	Inclination angle at reference time
22	omega_dot	Rate of right ascension
10	reserved	
16	af1	Clock coefficients af1
15	cuc	Amplitude of the cosine harmonic correction term to the argument of latitude
1	L5_flag	Signal health flag
14	i_dot	Rate of inclination angle
2	spare1	
15	cus	Amplitude of the sine harmonic correction term to the argument of latitude
1	s_flag	Signal health flag
22	af0	Clock coefficients af0
8	af2	Clock coefficients af2
2	spare2	
22	difference	Mean motion difference from computed value
10	WN	Week number
4	URA	User range accuracy
8	t_gd	Total group delay
8	IODEC	Issue of data for ephemeris and clock
12	spare3	
15	crc	Amplitude of the cosine harmonic correction term to the orbit radius
15	crs	Amplitude of the sine harmonic correction term to the orbit radius
2	spare5	
10	reserved	

6	reserved	
1	reserved	
1	Available	Contains 1 if ephemeris is available, 0 if not
1	Health	Contains 1 if the satellite is unhealthy, 0 if healthy
2	subframe_avail	Must be 0x3
1	nvm_reliable	Must be 1
10	spare6	

Example:

```
$PSTMDUMPEPHEMS
$PSTMEPHEM,1,64,0f06bc34bc345f5f5f84f400dea4ff00f9f63c239f0a35f81400fbff33420000ee632f2769
8ef001afa50da16cfca22e0b65a3e7a3cee27d700f7ffc616fe03*57
$PSTMEPHEM,2,64,0f06bc34bc344f4f4f78110019a5ff00b004fa1d1e0e3f04c8ffcaff19370000335157265
56ba9048eae0da1b6c346bd8f985c93ade10c76db001d00f8c7c503*58
$PSTMEPHEM,4,64,0f06bb34bb344b4b4b98050038a4ff000005351e110eea041b00b8ffd037000020b84
e26b5138b0425580ca16b211030e68b1a949cac9615f30066ffea92f603*06
$PSTMEPHEM,9,64,0f06bc34bc341818189c0a0069aaff005f06eb249a09ca0477ff6c00f72e00005131d8
27592b950a91010da1c7af88538e7ca1122fb9be3df4001300c4a0c203*52
```

2.2.5. \$PSTMCLRALMS

The command erases all the almanacs stored in the NVM backup memory.

Synopsis:

```
$PSTMCLRALMS<cr><lf>
```

Arguments:

None.

Results

- All almanacs, stored in the non-volatile backup memory, will be deleted.
- No message will be sent as reply.

Example:

```
$PSTMCLRALMS
```

2.2.6. \$PSTMDUMPALMANAC

The command dumps Almanac data. It sends out all almanacs stored in the backup memory.

Synopsis:

```
$PSTMDUMPALMANAC<cr><lf>
```

Arguments:

None.

Results

```
$PSTMDUMPALMANAC,<sat_id>,<N>,<byte1>,,<byteN>*<checksum><cr><lf>
```

Where:

Parameter	Format	Description
sat_id	Decimal, 2 digits	Satellite number
N	Decimal, 1 digit	Number of the almanac data bytes
byte1	Hexadecimal, 2 digits	First byte of the almanac data
byteN	Hexadecimal, 2 digits	Last byte of the almanac data
checksum	Hexadecimal, 2 digits	Checksum of the message bytes without *<checksum><cr><lf> characters.

The N Bytes that are in the message are the dump of a structures that contain all the information of the almanac. Data are stored in this structure according to the following table if the data are for GPS:

Bits	Structure Member	Description
8	satid	The satellite number
16	week	The week number for the epoch
8	toa	Reference time almanac
16	e	Eccentricity
16	delta_i	Rate of inclination angle
16	omega_dot	Rate of right ascension
24	root_A	Square root of semi-major axis
24	omega_zero	Longitude of ascending node of orbit plane at weekly epoch

24	perigee	Argument of perigee
24	mean_anomaly	Mean anomaly at reference time
11	af0	Constant clock correction
11	af1	First order clock correction
1	health	Contains 1 if the satellite is unhealthy, 0 if healthy
1	available	Contains 1 if almanac is available, 0 if not

For GLONASS, the table is:

Bits	Structure Member	Description
8	satid	The satellite number
16	week	The week number for the epoch
8	toa	Reference time almanac
5	n_A	Slot number (1...24)
5	H_n_A	Carrier frequency channel number
2	M_n_A	Type of satellite 00=GLONASS 01=GLONASS-M
10	tau_n_A	Satellite clock correction
15	epsilon_n_A	Eccentricity
21	t_lambda_n_A	Time of the first ascending node passage
21	lambda_n_A	Longitude of ascending node of orbit plane at almanac epoch
18	delta_i_n_A	Inclination angle correction to nominal value
7	delta_T_n_dot_A	Draconian period rate of change
22	delta_T_n_A	Draconian period correction
16	omega_n_A	Argument of perigee
1	health	Contains 1 if the satellite is unhealthy, 0 if healthy
1	available	Contains 1 if almanac is available, 0 if not
32	Tau_c	

11	NA
5	N4
16	Spare

The almanac of Galileo must be decoded according to the following table:

Bits	Structure Member	Description
16	satid	The satellite number
6	svid	Space vehicle identificator
16	week	The week number for the epoch
20	toa	Reference time almanac
13	delta_a	Delta of semi-major axis
11	e	Eccentricity
16	perigee	Argument of perigee
11	delta_i	Rate of inclination angle
16	omega_zero	Longitude of ascending node of orbit plane at weekly epoch
11	omega_dot	Rate of right ascension
16	mean_anomaly	Mean anomaly at reference time
16	af0	Constant clock correction
13	af1	First order clock correction
2	E5b_HS	E5 signal health status
2	E1B_HS	E1-B signal health status
4	ioda_1	Issue of data almanac 1
4	ioda_2	Issue of data almanac 2
1	health	Contains 1 if the satellite is unhealthy, 0 if healthy
2	reserved	Reserved for use by GNSS library
1	health	Contains 1 if the satellite is unhealthy, 0 if healthy

1	available	Contains 1 if almanac is available, 0 if not
---	-----------	--

For BeiDou:

Bits	Structure Member	Description
8	prn	PRN number of the corresponding almanac data
16	week	Almanac reference week number
8	toa	Almanac reference time
17	eccentricity	Eccentricity
11	af0	Satellite clock time bias correction coefficient
1	is_geo	Satellite orbit type
1	WNa_valid	
2	spare0	
17	omega_dot	Rate of right ascension
11	af1	Satellite clock time drift correction coefficient
4	spare1	
24	root_a	Square root of semi-major axis
8	spare2	
24	omega_zero	Longitude of ascending node of orbital plane at weekly epoch
8	spare3	
24	perigee	Argument of perigee
8	spare4	
24	mean_anomaly	Mean anomaly at reference time
8	spare5	
16	delta_i	Correction of inclination angle at reference time
1	health	Satellite health information
1	available	Contains 1 if almanac is available 0 if not.

8	last_received_toa
6	spare6

For IRNSS:

Bits	Structure Member	Description
10	WNa	Week number for almanac
16	toa	Almanac reference time
6	prn_al	PRN ID for almanac
16	eccentricity	Eccentricity
16	omega_dot	Rate of right ascension
24	inclination	Inclination
8	ISC	Inter signal correction
24	root_a	Square root of the semi-major axis
8	spare0	
24	omega_zero	Longitude of ascending node of orbit plane at weekly epoch
6	spare	
2	spare1	
24	perigee	Argument of perigee
6	prn	PRN ID
2	spare2	
24	mean_anomaly	Mean anomaly at reference time
8	spare3	
11	af0	Clock bias A0
11	af1	Clock bias A1
1	health	Contains 1 if the satellite is unhealthy, 0 if healthy
1	available	Contains 1 if almanac is available 0 if not.

8 spare4

Example:

```
$PSTMDUMPALMANAC
$PSTMALMANAC,1,32,011a06903f1f9f0d58fd0800d90ca1418713060099ee260034024200b4ffff00*1a
$PSTMALMANAC,2,32,021a0690944b78fe37fd0800770da141ef0c5b0060487700989bd800d8088000*1
a
$PSTMALMANAC,3,32,031a06904f68a2f540fd0800f60ca141922a2c003cae27009496cf00020a8000*15
$PSTMALMANAC,4,32,041a0690a94aeffd36fd0800390ca141afc95b00de7a1700dfc74e004ddebf00*13
$PSTMALMANAC,5,32,051a0690940eee0b5efd0800900ca141582b8600d3000b0060641200e40f8000*
14
```

2.2.7. \$PSTM**COLD**

The command performs a cold start.

Synopsis:

```
$PSTMCOLD,<Mask><cr><lf>
```

Arguments:

Parameter	Format	Description
Mask	Integer	Optional parameter to invalidate time, position, ephemeris and almanac: 0x1 – clear almanac 0x2 – clear ephemeris 0x4 – clear position 0x8 – clear time

Results

- Cold start initialization and system restart ¹⁾.
- If <Mask> parameter is used, only the selected GPS data is invalidated for this actual cold start. Multiple selects are supported (i.e. 0xD).
- If <Mask> parameter is not used, default is 0xE (clear ephemeris, time and position).

Example:

```
$PSTMCOLD,6
```

NOTE

¹⁾ The GPS engine will be reset. It is not a system reboot.

2.2.8. \$PSTMWARM

The command performs a warm start.

Synopsis:

```
$PSTMWARM<cr><lf>
```

Arguments:

None.

Results

- Warm start initialization and system restart¹⁾.

Example:

```
$PSTMWARM
```

NOTE

¹⁾ The GPS engine will be reset. It is not a system reboot.

2.2.9. \$PSTMHOT

The command performs a hot start.

Synopsis:

```
$PSTMHOT<cr><lf>
```

Arguments:

None.

Results

- System restart¹⁾

Example:

```
$PSTMHOT
```

NOTE

¹⁾ The GPS engine will be reset. It is not a system reboot.

2.2.10. \$PSTMSRR

The command executes a system reset. The GNSS firmware is rebooted.

Synopsis:

```
$PSTMSRR<cr><lf>
```

Arguments:

None.

Results

- The GNSS firmware reboots.
- No message will be sent as reply.

Example:

```
$PSTMSRR
```

2.2.11. \$PSTMSBASONOFF

The command suspends/resumes the SBAS software execution.

Synopsis:

```
$PSTMSBASONOFF<cr><lf>
```

Arguments:

None.

Results

- If SBAS was running, it will be suspended; if it was suspended, it will start to run.

Example:

```
$PSTMSBASONOFF
```

2.2.12. \$PSTMSBASSERVICE

The command changes the SBAS service.

Synopsis:

```
$PSTMSBASSERVICE,<service><cr><lf>
```

Arguments:

Parameter	Format	Description
service	Integer	SBAS service: 0 = WAAS 1 = EGNOS 2 = MSAS 3 = GAGAN 4 = SDCM 7 = OFF 15 = AUTO

Results

- The SBAS engine will put in tracker all the satellites which correspond to the specified service.
- With SBAS service OFF, no satellites are put in tracker. In that case, SBAS frames are to be provided to the SBAS engine through the **\$PSTMSBASM** command
- With SBAS AUTO, the SBAS engines automatically selects the appropriate SBAS service based on the computed user position latitude and longitude.
- If the command is executed successfully, the following message is returned:

```
$PSTMSBASSERVICEOK*<checksum><cr><lf>
```

- If there is any error, the following message is returned:

```
$PSTMSBASSERVICEERROR*<checksum><cr><lf>
```

Example:

```
$PSTMSBASSERVICE,15
```

2.2.13. \$PSTMGETRTC TIME

The command gets the current RTC time.

Synopsis:

```
$PSTMGETRTC TIME<cr><lf>
```

Arguments:

None.

Results

- System will send RTC data and status.

```
$PSTMGETRTC TIME,<time>,<date>,<rtc_status>,<time_validity>*<checksum><cr><lf>
```

Where:

Parameter	Format	Description
time	hhmmss.mms	Current time read on RTC
date	ddmmyy	Current date read on RTC
rtc_status	Decimal, 1 digit	Status: 0 - RTC_STATUS_INVALID 1 - RTC_STATUS_STORED 2 - RTC_STATUS_APPROXIMATE
time_validity	Decimal, 1 digit	Validity: 0 - NO_TIME 1 - FLASH_TIME 2 - USER_TIME 3 - USER_RTC_TIME 4 - RTC_TIME 5 - RTC_TIME_ACCURATE 6 - APPROX_TIME 8 - ACCURATE_TIME 9 - POSITION_TIME 10 - EPHEMERIS_TIME
checksum	Hexadecimal, 2 digits	Checksum of the message bytes without *<checksum><cr><lf> characters.

Example:

```
$PSTMGETRTCETIME
```

2.2.14. \$PSTMSETCONSTMASK

The command sets the GNSS constellation mask. It allows switching the GNSS constellation at run-time. In case of reset, constellation mask is restored to default value.

Synopsis:

```
$PSTMSETCONSTMASK,<constellation_mask><cr><lf>
```

Arguments:

Parameter	Format	Description
constellation_mask	1 - 9999	It is a bit mask where each bit enables/disables a specific constellation independently by the others: bit 0: Enabling/disabling GPS constellation bit 1: Enabling/disabling GLONASS constellation

bit 2: Enabling/disabling QZSS constellation
 bit 3: Enabling/disabling Galileo constellation
 bit 7: Enabling/disabling BeiDou constellation
 bit 10: Enabling/disabling IRNSS constellation

Results

- If the command is executed successfully, the following message is returned:

```
$PSTMSETCONSTMASKOK,<constellation_mask>*<checksum><cr><lf>
```

- If there is any error, the following message is returned:

```
$PSTMSETCONSTMASKERROR*<checksum><cr><lf>
```

Example:

Enabling GPS only:

```
$PSTMSETCONSTMASK,1
```

Enabling GLONASS only:

```
$PSTMSETCONSTMASK,2
```

Enabling GPS and GLONASS:

```
$PSTMSETCONSTMASK,3
```

Enabling IRNSS:

```
$PSTMSETCONSTMASK,1024
```

2.2.15. \$PSTMPPS

The command allows interfacing all parameters for Pulse Per Second management. This is a parametric command.

Synopsis:

```
$PSTMPPS,<cmd_mode>,<cmd_type>,<par_1>,...,<par_N><cr><lf>
```

Arguments:

Parameter	Format	Description
cmd_mode	Decimal, 1 digit	Select the command operation mode: 1 = GET operation (to get data from PPS manager) 2 = SET operation (to set data into PPS manager)
cmd_type	Decimal	1 = PPS_IF_ON_OFF_CMD 2 = PPS_IF_OUT_MODE_CMD 3 = PPS_IF_REFERENCE_CONSTELLATION_CMD

4 = PPS_IF_PULSE_DELAY_CMD
 5 = PPS_IF_PULSE_DURATION_CMD
 6 = PPS_IF_PULSE_POLARITY_CMD
 7 = PPS_IF_PULSE_DATA_CMD
 8 = PPS_IF_FIX_CONDITION_CMD
 9 = PPS_IF_SAT_THRESHOLD_CMD
 10 = PPS_IF_ELEVATION_MASK_CMD
 11 = PPS_IF_CONSTELLATION_MASK_CMD
 12 = PPS_IF_TIMING_DATA_CMD
 13 = PPS_IF_POSITION_HOLD_DATA_CMD
 14 = PPS_IF_AUTO_HOLD_SAMPLES_CMD
 15 = PPS_IF_TRAIM_CMD
 16 = PPS_IF_TRAIM_USED_CMD
 17 = PPS_IF_TRAIM_RES_CMD
 18 = PPS_IF_TRAIM_REMOVED_CMD
 19 = PPS_IF_REFERENCE_TIME_CMD
 20 = PPS_IF_CONSTELLATION_RF_DELAY_CMD

par_1 ... par_N

Parameters list according to the command type specification (see below).

2.2.15.1. Getting PPS Data (cmd_mode=1)

- **PPS_IF_PULSE_DATA_CMD**

```
$PSTMPPS,1,7<cr><lf>
```

Reply:

```
$PSTMPPS,1,7,<out_mode>,<reference_time>,<pulse_delay>,<pulse_duration>,<pulse_polarity><cr><lf>
```

Parameter	Format	Description
out_mode	Decimal, 1 digit	0 = PPS always generated 1 = PPS generated on even seconds 2 = PPS generated on odd seconds
reference_time	Decimal, 1 digit	0 = UTC 1 = GPS_UTC 2 = GLONASS_UTC 3 = UTC_SU 4 = GPS_UTC_FROM_GLONASS 5 = COMPASS_UTC 6 = UTC_NTSC 7 = GST

8 = UTC_GST

9 = GPS_FROM_GST

NOTES:

UTC(SU) is the Soviet Union UTC, it is derived from GLONASS time applying the UTC delta time downloaded from GLONASS satellites.

GPS_UTC_FROM_GLONASS is the GPS time derived from GLONASS time applying the GPS delta time downloaded from GLONASS satellites.

If the software is configured to work in GLONASS only mode, UTC(SU) is identical to UTC and GPS_UTC_FROM_GLONASS is identical to GPS_UTC.

pulse_delay	Decimal	Pulse delay [ns]
pulse_duration	Double	Pulse duration [s]
pulse_polarity	Decimal, 1 digit	0 = not inverted 1 = inverted

● **PPS_IF_TIMING_DATA_CMD**

\$PSTMPPS,1,12<cr><lf>

Reply:

\$PSTMPPS,1,12,<fix_condition>,<sat_th>,<elevation_mask>,<constellation_mask>,<gps_rf_delay>,<glonass_rf_delay>*<checksum><cr><lf>

Parameter	Format	Description
fix_condition	Decimal, 1 digit	1 = No fix 2 = 2D fix 3 = 3D fix
sat_th	Decimal	Minimum number of satellites for the PPS generation
elevation_mask	Decimal	Minimum satellite elevation for satellite usage in timing filtering
constellation_mask	Decimal (bit mask)	Satellite constellation selection for usage in timing filtering. bit0 = GPS bit1 = GLONASS bit7 = BeiDou
gps_rf_delay	Decimal	GPS path RF delay [ns]
glonass_rf_delay	Decimal	GLONASS path RF delay [ns]

● PPS_IF_POSITION_HOLD_DATA_CMD

\$PSTMPPS,1,13<cr><lf>

Reply:

\$PSTMPPS,1,13,<on_off>,<lat>,<lat_dir>,<lon>,<lon_dir>,<h_msl><cr><lf>

Parameter	Format	Description
on_off	Decimal, 1 digit	0 = Position hold disabled 1 = Position hold enabled
lat	DDMM.MMMMM	Position hold position latitude
lat_dir	"N" or "S"	North or south direction
lon	DDDMM.MMMMM	Position hold position longitude
lon_dir	"E" or "W"	East or west direction
h_msl	Double	Position hold mean see level altitude

● PPS_IF_TRAIM_CMD

\$PSTMPPS,1,15<cr><lf>

Reply:

\$PSTMPPS,1,15,<traim_enabled>,<traim_solution>,<ave_error>,<used_sats>,<removed_sats><cr><lf>

Parameter	Format	Description
traim_enabled	Decimal, 1 digit	TRAIM ON/OFF status: 0 = OFF 1 = ON
traim_solution	Decimal, 1 digit	TRAIM algorithm status: 0 = UNDER alarm 1 = OVER alarm 2 = UNKNOWN
ave_error	Decimal	Average time error [ns]
used_sats	Decimal	Number of satellite used for timing correction
removed_sats	Decimal	Number of satellites removed by the timing correction

- **PPS_IF_TRAIM_USED_CMD**

```
$PSTMPPS,1,16<cr><lf>
```

Reply:

```
$PSTMPPS,1,16,<trainm_enabled>,<used_sats>,<sat1>...,<satN><cr><lf>
```

Parameter	Format	Description
trainm_enabled	Decimal, 1 digit	TRAIM ON/OFF status: 0 = OFF 1 = ON
used_sats	Decimal	Number of satellite used for timing correction
sat1..satN	Decimal	List of satellites IDs

- **PPS_IF_TRAIM_RES_CMD**

```
$PSTMPPS,1,17<cr><lf>
```

Reply:

```
$PSTMPPS,1,17,<trainm_enabled>,<used_sats>,<res1>...,<resN><cr><lf>
```

Parameter	Format	Description
trainm_enabled	Decimal, 1 digit	TRAIM ON/OFF status: 0 = OFF 1 = ON
used_sats	Decimal	Number of satellite used for timing correction
res1..resN	Decimal	List of satellites residuals [ns] Each residual corresponds to the satellite in the used sat list at the same message position

- **PPS_IF_TRAIM_REMOVED_CMD**

```
$PSTMPPS,1,18<cr><lf>
```

Reply:

```
$PSTMPPS,1,18,<trainm_enabled>,<rem_sats>,<sat1>...,<satN><cr><lf>
```

Parameter	Format	Description
trainm_enabled	Decimal, 1 digit	TRAIM ON/OFF status:

		0 = OFF 1 = ON
rem_sats	Decimal	Number of satellite removed by timing correction
sat1..satN	Decimal	List of satellites IDs

2.2.15.2. Setting PPS Data (cmd_mode=2)

- **PPS_IF_ON_OFF_CMD**

```
$PSTMPPS,2,1,<on_off><cr><lf>
```

Parameter	Format	Description
on_off	Decimal, 1 digit	0 = PPS disabled 1 = PPS enabled

- **PPS_IF_OUT_MODE_CMD**

```
$PSTMPPS,2,2,<out_mode><cr><lf>
```

Parameter	Format	Description
out_mode	Decimal, 1 digit	0 = PPS always generated 1 = PPS generated on even seconds 2 = PPS generated on odd seconds

- **PPS_IF_REFERENCE_TIME_CMD**

```
$PSTMPPS,2,19,<reference_time><cr><lf>
```

Parameter	Format	Description
reference_time	Decimal, 1 digit	0 = UTC 1 = GPS_UTC. 2 = GLONASS_UTC. 3 = UTC_SU 4 = GPS_UTC_FROM_GLONASS 5 = COMPASS_UTC 6 = UTC_NTSC 7 = GST 8 = UTC_GST 9 = GPS_FROM_GST NOTES:

UTC(SU) is the Soviet Union UTC, it is derived from GLONASS time applying the UTC delta time downloaded from GLONASS satellites.

GPS_UTC_FROM_GLONASS is the GPS time derived from GLONASS time applying the GPS delta time downloaded from GLONASS satellites.

If the software is configured to work in GLONASS only mode, UTC(SU) is identical to UTC and GPS_UTC_FROM_GLONASS is identical to GPS_UTC.

- **PPS_IF_PULSE_DELAY_CMD**

```
$PSTMPPS,2,4,<pulse_delay><cr><lf>
```

Parameter	Format	Description
pulse_delay	Decimal	Pulse delay [ns]

- **PPS_IF_CONSTELLATION_RF_DELAY_CMD**

```
$PSTMPPS,2,20,<sat_type><time_delay><cr><lf>
```

Parameter	Format	Description
sat_type	Decimal	Satellite constellation type: 0 = GPS 1 = GLONASS 3 = Galileo 7 = COMPASS
time_delay	Decimal	Time delay [ns]

- **PPS_IF_PULSE_DURATION_CMD**

```
$PSTMPPS,2,5,<pulse_duration><cr><lf>
```

Parameter	Format	Description
pulse_duration	Double	Pulse duration [s]

- **PPS_IF_PULSE_POLARITY_CMD**

```
$PSTMPPS,2,6,<pulse_polarity><cr><lf>
```

Parameter	Format	Description
pulse_polarity	Decimal, 1 digit	0 = not inverted 1 = inverted

- **PPS_IF_PULSE_DATA_CMD**

```
$PSTMPPS,2,7,<out_mode>,<reference_time>,<pulse_delay>,<pulse_duration>,<pulse_polarity><cr><lf>
```

Parameter	Format	Description
out_mode	Decimal, 1 digit	0 = PPS always generated 1 = PPS generated on even seconds 2 = PPS generated on odd seconds
reference_time	Decimal, 1 digit	0 = UTC 1 = GPS_UTC 2 = GLONASS_UTC 3 = UTC_SU 4 = GPS_UTC_FROM_GLONASS
pulse_delay	Decimal	Pulse delay [ns]
pulse_duration	Double	Pulse duration [s]
pulse_polarity	Decimal, 1 digit	0 = not inverted 1 = inverted

- **PPS_IF_FIX_CONDITION_CMD**

```
$PSTMPPS,2,8,<fix_condition><cr><lf>
```

Parameter	Format	Description
fix_condition	Decimal, 1 digit	1 = No fix 2 = 2D fix 3 = 3D fix

- **PPS_IF_SAT_THRESHOLD_CMD**

```
$PSTMPPS,2,9,<sat_th><cr><lf>
```

Parameter	Format	Description
sat_th	Decimal	Minimum number of satellites for the PPS generation

● **PPS_IF_ELEVATION_MASK_CMD**

\$PSTMPPS,2,10,<elevation_mask><cr><lf>

Parameter	Format	Description
elevation_mask	Decimal	Minimum satellite elevation for satellite usage in timing filtering

● **PPS_IF_CONSTELLATION_MASK_CMD**

\$PSTMPPS,2,11,<constellation_mask><cr><lf>

Parameter	Format	Description
constellation_mask	Decimal (bit mask)	<p>Satellite constellation selection for usage in timing filtering.</p> <p>bit0 = GPS bit1 = GLONASS bit7 = BeiDou</p> <p>NOTES:</p> <p>This parameter enables the usage of mixed constellations satellites in the timing filtering. If bit0 is enabled GPS satellites are used to correct the GLONASS reference time together with GLONASS satellites. If bit1 is enabled, GLONASS satellites are used to correct the GPS reference time together with the GPS satellites. When constellation mask is zero (default) only GPS sats are used to correct the GPS reference time and only GLONASS sats are used to correct the GLONASS reference time.</p> <p>Same description is valid also for GPS and BeiDou constellations enabling/disabling bit0 and bit7.</p>

● **PPS_IF_TIMING_DATA_CMD**

\$PSTMPPS,2,12,<fix_condition>,<sat_th>,<elevation_mask>,<constellation_mask><cr><lf>

Parameter	Format	Description
fix_condition	Decimal, 1 digit	<p>1 = No fix 2 = 2D fix 3 = 3D fix</p>
sat_th	Decimal	Minimum number of satellites for the PPS generation

elevation_mask	Decimal	Minimum satellite elevation for satellite usage in timing filtering
constellation_mask	Decimal (bit mask)	Satellite constellation selection for usage in timing filtering. bit0 = GPS bit1 = GLONASS

- **PPS_IF_POSITION_HOLD_DATA_CMD**

```
$PSTMPSS,2,13,<on_off>,<lat>,<lat_dir>,<lon>,<lon_dir>,<h_msl><cr><lf>
```

Parameter	Format	Description
on_off	Decimal, 1 digit	0 = Position hold disabled 1 = Position hold enabled
lat	DDMM.MMMMMM	Position hold position latitude
lat_dir	"N" or "S"	North or south direction
lon	DDDMM.MMMMMM	Position hold position longitude
lon_dir	"E" or "W"	East or west direction
h_msl	Double	Position hold mean see level altitude

- **PPS_IF_AUTO_HOLD_SAMPLES_CMD**

```
$PSTMPSS,2,14,<auto_ph_samples><cr><lf>
```

Parameter	Format	Description
auto_ph_samples	Decimal, 1 digit	Number of position samples for the auto position algorithm. If the number of samples is set to "0" the auto position hold feature is disabled. The position average evaluation is restarted every time the command is executed.

- **PPS_IF_TRAIM_CMD**

```
$PSTMPSS,2,15,<on_off>,<alarm><cr><lf>
```

Parameter	Format	Description
on_off	Decimal, 1 digit	0 = TRAIM disabled 1 = TRAIM enabled
alarm	Double	TRAIM alarm [s] – scientific notation is allowed

Results:

According to the operation mode and the command type, data is set into or is retrieved from the PPS manager.

2.2.16. \$PSTMFORCESTANDBY

The command forces the platform to enter into standby mode.

Synopsis:

```
$PSTMFORCESTANDBY,<duration><cr><lf>
```

Arguments:

Parameter	Format	Description
duration	Decimal, 5 digits	Duration of the standby time in seconds

Results:

- If the command is executed successfully, the following message is returned:

```
$PSTMFORCESTANDBYOK*<checksum><cr><lf>
```

- If there is any error, the following message is returned:

```
$PSTMFORCESTANDBYERROR*<checksum><cr><lf>
```

2.2.17. \$PSTMGEOFENCEREQ

The command forces the GNSS receiver to send a PSTMGEOFENCE message to know internal geo-fence subsystem status.

Synopsis:

```
$PSTMGEOFENCEREQ*<cr><lf>
```

Arguments:

None.

Results:

- If there are no errors, the ST GNSS replies with the **\$PSTMGEOFENCESTATUS** message.
- If there is any error, the following message will be returned:

```
$PSTMGEOFENCEREQERROR*<checksum><cr><lf>
```

2.2.18. \$PSTMODOSTART

The command enables and resets the odometer subsystem, which begins evaluating the ground distance from the current resolved position.

The odometer must be enabled otherwise the request will be rejected with error. To enable the odometer it is required a change in firmware configuration which can be done also through the command **\$PSTMCFGODO**.

Synopsis:

```
$PSTMODOSTART<cr><lf>
```

Arguments:

None.

Results

- If there are no errors, the following message is returned:

```
$PSTMODSTARTOK*<checksum><cr><lf>
```

- If there is any error, the following message is returned:

```
$PSTMODSTARTERROR*<checksum><cr><lf>
```

2.2.19. \$PSTMODOSTOP

The command stops the odometer subsystem.

The odometer must be enabled otherwise the request will be rejected with error. To enable the odometer it is required a change in firmware configuration which can be done also through the command **\$PSTMCFGODO**.

Synopsis:

```
$PSTMODOSTOP<cr><lf>
```

Arguments:

None.

Results

- If there are no errors, the following message is returned:

```
$PSTMODSTOPOK*<checksum><cr><lf>
```

- If there is any error, the following message is returned:

```
$PSTMODSTOPERROR*<checksum><cr><lf>
```

2.2.20. \$PSTMODOREQ

The command requests the odometer status.

The odometer must be enabled otherwise the request will be rejected with error. To enable the odometer it is required a change in firmware configuration which can be done also through the command **\$PSTMCFGODO**.

Synopsis:

```
$PSTMODOREQ<cr><lf>
```

Arguments:

None.

Results

- If there are no errors, a message **\$PSTMODO** is returned.
- If there is any error, the following message is returned:

```
$PSTMODOREQERROR*<checksum><cr><lf>
```

2.2.21. \$PSTMCFGCONST

The command configures constellation.

Synopsis:

```
$PSTMCFGCONST,<gps>,<glonass>,<galileo>,<qzss>,<beidou>,<irnss><cr><lf>
```

Arguments:

Parameter	Format	Description
gps	Unsigned	GPS constellation status: 0 = Constellation off 1 = Constellation tracked 2 = Constellation tracked and used in positioning
glonass	Unsigned	GLONASS constellation status: 0 = Constellation off 1 = Constellation tracked 2 = Constellation tracked and used in positioning
galileo	Unsigned	Galileo constellation status: 0 = Constellation off 1 = constellation tracked 2 = Constellation tracked and used in positioning

		QZSS constellation status: 0 = Constellation off 1 = constellation tracked 2 = Constellation tracked and used in positioning
qzss	Unsigned	BeiDou constellation status: 0 = Constellation off 1 = Constellation tracked 2 = Constellation tracked and used in positioning
beidou	Unsigned	IRNSS constellation status: 0 = Constellation off 1 = constellation tracked 2 = Constellation tracked and used in positioning
irnss*	Unsigned	

Results:

- If the command syntax is correct and parameters are correctly set, the following confirmation message is returned:

```
$PSTMCFGCONFOK*<checksum><cr><lf>
```

- If there is any error, the following message is returned:

```
$PSTMCFGCONFERROR*<checksum><cr><lf>
```

NOTE

“*” means under development.

2.2.22. \$PSTMODORESET

This command resets the odometer subsystem.

The odometer must be enabled otherwise the request will be rejected with error. To enable the odometer it is required a change in firmware configuration which can be done also through the command **\$PSTMCFGODO**.

Synopsis:

```
$PSTMODORESET,<odo_mask><cr><lf>
```

Arguments:

Parameter	Format	Description
odo_mask	Decimal	The odometers to be reset: 0 = none 1 = Odo-A

-
- | |
|------------------------------|
| 2 = Odo-B |
| 3 = Odo-A and Odo-B |
| 4 = Odo-Tot |
| 5 = Odo-A and Odo-Tot |
| 6 = Odo-B and Odo-Tot |
| 7 = Odo-A, Odo-B and Odo-Tot |
-

Results

- If there are no errors, the following message is returned:

```
$PSTMODORESETOK*<checksum><cr><lf>
```

- If there is any error, the following message is returned:

```
$PSTMODORESETERROR*<checksum><cr><lf>
```

2.2.23. \$PSTMCFGPORT

The command configures a general-purpose port for NMEA, STBIN, DEBUG or RTCM purpose.

Synopsis:

```
$PSTMCFGPORT,<port_type>,<protocol_type>,<par_1>,<par_2>,...,<par_N><cr><lf>
```

Arguments:

Parameter	Format	Description
port_type	Decimal, 1 digit	Select the port type: 0 = UART 1 = I2C
protocol_type	Decimal, 1 digit	Select the protocol type: 0 = NMEA
par_1 ... par_N	Integer	Parameters list according to the command type Specification (see below).

Results:

- One or more parameters of swconfig are set according to the command parameters. If there are no errors, the following message is returned:

```
$PSTMCFGPORTOK*<checksum><cr><lf>
```

- If there is any error, the following message is returned:

```
$PSTMCFGPORTERROR*<checksum><cr><lf>
```

2.2.23.1. Parameters when port_type is UART

Parameter	Format	Description
portnumb	From 0 to 255	UART GPIO ID (Linearly addressed)
baudrate	Integer	The port baud rate. Allowed values are: 300, 600, 1200, 2400, 4800, 9600, 14400, 19200, 38400, 57600, 115200, 230400, 460800, 921600

2.2.23.2. Parameters when port_type is I2C

Parameter	Format	Description
slaveaddr	Hexadecimal, 2 Bytes	The I2C slave address
mode	Decimal, 1 digit	0 = Speed mode STANDARD 1 = Speed mode FAST 2 = Speed mode HS

2.2.24. \$PSTMCFGMSGL

The command configures the message list.

Synopsis:

```
$PSTMCFGMSGL,<listid>,<rate>,<listlow>,<listhigh><cr><lf>
```

Arguments:

Parameter	Format	Description
listid	Decimal, 1 digit	List selector: 0 = NMEA list 0
rate	From 0 to 255	Message list rate scaler
listlow	Hexadecimal, 8 digits	Low 32 bits
listhigh	Hexadecimal, 8 digits	High 32 bits

For each bit:

- 0 means feature disabled
- 1 means feature enabled

Bit	Bitmask(32 bits)	Function
Low 32 bits		
0	0x1	\$GPGNS message
1	0x2	\$GPGGA message
2	0x4	\$GPGSA message
3	0x8	\$GPGST message
4	0x10	\$GPVTG message
5	0x20	Reserved
6	0x40	\$GPRMC message
7	0x80	Reserved
8	0x100	Reserved
9	0x200	Reserved
10	0x400	Reserved
11	0x800	Reserved
12	0x1000	Reserved
13	0x2000	Reserved
14	0x4000	Reserved

15	0x8000	Reserved
16	0x10000	Reserved
17	0x20000	Reserved
18	0x40000	Reserved
19	0x80000	\$GPGSV message
20	0x100000	\$GPGLL message
21	0x200000	Reserved
22	0x400000	Reserved
23	0x800000	Reserved
24	0x1000000	\$GPZDA message
25	0x2000000	Reserved
26	0x4000000	Reserved
27	0x8000000	Reserved
28	0x10000000	Reserved
29	0x20000000	Reserved
30	0x40000000	Reserved
31	0x80000000	Reserved
High 32 bits		
32	0x1	Reserved
33	0x2	Reserved
34	0x4	Reserved
35	0x8	Reserved
36	0x10	\$PSTMANTENNASTATUS message
37	0x20	Reserved
38	0x40	Reserved
39	0x80	\$GPDTM message

40	0x100	Reserved
41	0x200	Reserved
42	0x400	Reserved
43	0x800	Reserved
44	0x1000	Reserved
45	0x2000	\$GPGBS message
46	0x4000	Reserved
47	0x8000	Reserved
48	0x10000	Reserved
49	0x20000	Reserved
50	0x40000	\$PSTMODO message
51	0x80000	\$PSTMGEFENCESTATUS message
52	0x100000	Reserved
53	0x200000	Reserved
54	0x400000	Reserved
55	0x800000	Reserved
56	0x1000000	Reserved
57	0x2000000	Reserved
58	0x4000000	Reserved
59	0x8000000	Reserved
60	0x10000000	Reserved
61	0x20000000	Reserved
62	0x40000000	Reserved
63	0x80000000	\$GARLM message

Results:

- One or more parameters of swconfig are set according to the command parameters. If there are no errors, the following message is returned:

\$PSTMCFGMSGLOK*<checksum><cr><lf>

- If there is any error, the following message is returned:

\$PSTMCFGMSGLError*<checksum><cr><lf>

2.2.25. \$PSTMCFGAGPS

The command configures the Assisted GPS.

Synopsis:

\$PSTMCFGAGPS,<en_agps><cr><lf>

Arguments:

Parameter	Format	Description
en_agps	Decimal	Enable/disable AGPS engine 0 = AGPS disables 1 = AGPS enabled

Results:

- One or more parameters of swconfig are set according to the command parameters. If there are no errors, the following message is returned:

\$PSTMCFGAGPSOK*<checksum><cr><lf>

- If there is any error, the following message is returned:

\$PSTMCFGAGPSERROR*<checksum><cr><lf>

2.2.26. \$PSTMCFGAJM

The command configures the anti-jamming algorithm.

Synopsis:

\$PSTMCFGAJM,<gpsmode>,<glonassmode><cr><lf>

Arguments:

Parameter	Format	Description
gpsmode	Decimal, 1 digit	Notch filter on GPS path: 0 = Disable 1 = Normal mode 2 = Auto mode

		Notch filter on GLONASS path: 0 = Disable 1 = Normal mode 2 = Auto mode
glonassmode	Decimal, 1 digit	

Results:

- One or more parameters of swconfig are set according to the command parameters. If there are no errors, the following message is returned:

```
$PSTMCFGAGPSOK*<checksum><cr><lf>
```

- If there is any error, the following message is returned:

```
$PSTMCFGAGPSERROR*<checksum><cr><lf>
```

2.2.27. \$PSTMCFGODO

The command configures the odometer.

Synopsis:

```
$PSTMCFGODO,<en>,<auto>,<enmsg>,<alarm><cr><lf>
```

Arguments:

Parameter	Format	Description
en	Decimal, 1 digit	Enable/disable the odometer: 0 = Odometer disabled 1 = Odometer enabled
auto	Decimal, 1 digit	Enable/disable the auto-start (e.g. odometer is automatically started on start-up and no \$PSTMODOSTART command is required): 0 = Auto-start disabled 1 = Auto-start enabled
enmsg	Decimal, 1 digit	Enable/disable odometer related periodic messages: 0 = Periodic message disabled 1 = Periodic message enabled
alarm	Decimal, 0 – 65535	Distance travelled between two NMEA messages

Results

- One or more parameters of swconfig are set according to the command parameters. If there are no errors, the following message is returned:

```
$PSTMCFGODOOK*<checksum><cr><lf>
```

- If there is any error, the following message is returned:

```
$PSTMCFGODOERROR*<checksum><cr><lf>
```

2.2.28. \$PSTMCFGEOFENCE

The command allows to configure Geo-fencing feature enabling circles and choosing tolerance.

Synopsis:

```
$PSTMCFGEOFENCE,<en>,<tol><cr><lf>
```

Arguments:

Parameter	Format	Description
en	Decimal, 1 digit	Enable/disable the geo fencing: 0 = Geo-fencing disabled 1 = Geo-fencing enabled
tol	Decimal, 1 digit	Tolerance: 0 = none 1 = level 1 2 = level 2 3 = level 3

Results

- One or more parameters of swconfig are set according to the command parameters. If there are no errors, the following message is returned:

```
$PSTMCFGEOFENCEOK*<checksum><cr><lf>
```

- If there is any error, the following message is returned:

```
$PSTMCFGEOFENCEERROR*<checksum><cr><lf>
```

2.2.29. \$PSTMCFGGEOCIR

The command allows to configure a circle of geo-fencing feature.

Synopsis:

```
$PSTMCFGGEOCIR,<circleid>,<en>,<lat>,<lon>,<rad><cr><lf>
```

Arguments:

Parameter	Format	Description
circleid	Decimal, 1 digit	The circle ID

		From 0 to 4
en	Boolean	Enable/disable the circle 0 = Disable, 1 = Enable
lat	Double	N-th circle latitude
lon	Double	N-th circle longitude
rad	Double	N-th circle radius

Results

- One or more parameters of swconfig are set according to the command parameters. If there are no errors, the following message is returned:

```
$PSTMCFGGEOCIROK*<checksum><cr><lf>
```

- If there is any error, the following message is returned:

```
$PSTMCFGGEOCIRERROR*<checksum><cr><lf>
```

2.2.30. \$PSTMSETTHTRK

The command configures the CN0 and elevation mask angle thresholds for tracking. This command changes these parameters at run-time and no reset is required. In case of reset tracking CN0 and elevation mask angle are restored to default value.

Synopsis:

```
$PSTMSETTHTRK,<cn0>,<el><cr><lf>
```

Arguments:

Parameter	Format	Description
cn0	Decimal	Tracking CN0 threshold as dB
el	Double	Tracking elevation mask angle as degree

Results

- If the command syntax is correct and the tracking CN0 and Elevation Mask are correctly changed, the following message is returned:

```
$PSTMSETTHTRKOK*<checksum><cr><lf>
```

- If there is any error, the following message is returned:

```
$PSTMSETTHTRKERROR*<checksum><cr><lf>
```

2.2.31. \$PSTMSETTHPOS

The command configures the CN0 and elevation mask angle thresholds for positioning. This command changes these parameters at run-time and no reset is required. In case of reset positioning CN0 and elevation mask angle are restored to default value.

Synopsis:

```
$PSTMSETTHPOS,<cn0>,<el><cr><lf>
```

Arguments:

Parameter	Format	Description
cn0	Decimal	Positioning CN0 threshold as dB
el	Double	Positioning elevation mask angle as degree

Results

- If the command syntax is correct and the positioning CN0 and elevation mask are correctly changed, the following message is returned:

```
$PSTMSETTHTRKOK*<checksum><cr><lf>
```

- If there is any error, the following message is returned:

```
$PSTMSETTHTRKERROR*<checksum><cr><lf>
```

2.2.32. \$PSTMSETANTSENSOPMODE

The command set antenna sensing operating mode: auto or manual.

Synopsis:

```
$PSTMSETANTSENSOPMODE,<operating_mode><cr><lf>
```

Arguments:

Parameter	Format	Description
operating_mode	Decimal, 1 digit	Select the antenna sensing operating mode: 0 = Auto 1 = Manual

Results

- Antenna sensing operating mode is set according to the command parameter. If there are no errors, the following message is returned:

\$PSTMSETANTSENSOPMODEOK*<checksum><cr><lf>

- If there is any error, the following message is returned:

\$PSTMSETANTSENSOPMODEERROR*<checksum><cr><lf>

2.2.33. \$PSTMSETANTSENSMANUAL

Manage the Antenna Sensing ON-OFF, RF switching, antenna status reading and antenna detection enabling/disabling by command. It can be used only after set Antenna Operating mode to MANUAL.

Synopsis:

\$PSTMSETANTSENSMANUAL,<power_onoff>,<rf_switch_onoff>,<ant_status_reading_en>,<ant_sens_onoff><cr><lf>

Arguments:

Parameter	Format	Description
power_onoff	Decimal, 1 digit	Antenna power ON/OFF by command: 0 = Do nothing 1 = Antenna power ON 2 = Antenna power OFF
rf_switch_onoff	Decimal, 1 digit	Antenna RF switching by command 0 = Do nothing 1 = Switch to external antenna 2 = Switch to internal antenna
ant_status_reading_en	Decimal, 1 digit	0 = Do nothing 1 = Antenna status reading
ant_sens_onoff	Decimal, 1 digit	Antenna sensing feature ON/OFF 0 = Antenna sensing ON (update status ON and NMEA sentence ON) 1 = Antenna sensing OFF (update status OFF and NMEA sentence OFF)

Results

- One or more antenna features are set according to the command parameters. If there are no errors, the following message is returned:

\$PSTMSETANTSENSMANUAL,<power_onoff>,<rf_switch_onoff>,<op_mode>,<antenna_status>,<ant_sens_onoff>*<checksum><cr><lf>

- If antenna operating mode is auto, it returns error. In this case, the following message is returned:

\$PSTMSETANTSENSMANUALERROR*<checksum><cr><lf>

Example

- Switch to external antenna manually

```
$PSTMSETANTSENSOPMODE,1  
$PSTMSETANTSENSOPMODEOK*10  
$PSTMSETANTSENSMANUAL,1,1,0,0  
$PSTMSETANTSENSMANUAL,1,1,1,3,0*0C
```

- Switch to internal antenna manually

```
$PSTMSETANTSENSOPMODE,1  
$PSTMSETANTSENSOPMODEOK*10  
$PSTMSETANTSENSMANUAL,1,1,0,0  
$PSTMSETANTSENSMANUAL,1,2,1,3,0*0F
```

2.3. System Commands

The GNSS software utilizes a “Configuration Data Block” that holds the working parameters for the system.

2.3.1. \$PSTMSAVEPAR

The command saves current configuration data block into the backup memory.

Synopsis:

```
$PSTMSAVEPAR<cr><lf>
```

Arguments:

None.

Results:

- The current configuration data block, including changed parameters, will be stored into the backup memory (NVM).
If there is no error, the following message is returned:

```
$PSTMSAVEPAROK
```

- If there is any error, the following message is returned:

```
$PSTMSAVEPARERROR
```

Example:

```
$PSTMSAVEPAR
```

2.3.2. \$PSTMRESTOREPAR

The command restores the factory setting parameters. The configuration data block stored in NVM, if present, will be invalidated. Any changed parameter will be lost.

Synopsis:

```
$PSTMRESTOREPAR<cr><lf>
```

Arguments:

None.

Results:

- The factory setting parameters will be restored and the configuration block in the backup memory will be lost. A system reboot is needed to complete the factory reset restoring ad to get system working with default setting.

If there is no error, the following message is returned:

```
$PSTMRESTOREPAROK
```

- If there is any error, the following message is returned:

```
$PSTMRESTOREPARERROR
```

Example:

```
$PSTMRESTOREPAR
```

3 Messages

3.1. Standard NMEA Messages List

Syntax	Default	Description
\$--RMC	ON	NMEA: Recommended minimum specific GNSS data
\$--VTG	ON	NMEA: Track made good and ground speed
\$--GGA	ON	NMEA: Global position system fix data
\$--GSA	ON	NMEA: GPS DOP and active satellites.
\$--GSV	ON	NMEA: GPS satellites in view.
\$--GLL	ON	NMEA: Geographic position latitude/longitude

3.2. ST NMEA Messages List

Syntax	Default	Description
\$PSTMANTENNASTATUS	ON	ST: Reports the status of the antenna
\$PSTMGEOFENCESTATUS	OFF	ST: Reports the status of the geo-fence
\$PSTMODO	OFF	ST: Reports the values of the odometer

3.3. Standard NMEA Messages Specification

These messages are defined within the “NMEA 0183” specification.

Table 2: Structure of Standard NMEA Messages

Filed	Length (Bytes)	Description
\$	1	Each NMEA message starts with '\$'
Talker ID	1~2	GP: If system works in GPS only mode GL: If system works in GLONASS only mode GA: If system works in Galileo only mode BD: If system works in BeiDou only mode QZ: If system works in QZSS only mode GN: If system works in multi-constellation mode.
NMEA Message ID	3	NMEA message ID
Data Field	Variable, depend on the NMEA message type	Data fields, delimited by comma ','
*	1	End character of data field
Checksum	2	A hexadecimal number calculated by exclusive OR of all characters between '\$' and '*'
<CR><LF>	2	Each NMEA message ends with 'CR' and 'LF'

NOTE

The default output message of L89 series has the following six sentences: RMC, VTG, GGA, GSA, GSV and GLL.

3.3.1. \$--RMC

Recommended minimum specific GPS/transit data. Time, date, position and speed data provided by the GNSS receiver.

Format for NMEA 0183 Rev 3.01 (Default):

\$GPRMC,<Timestamp>,<Status>,<Lat>,<N/S>,<Long>,<E/W>,<Speed>,<Trackgood>,<Date>,<MagVar>,<MagVarDir>,<mode><checksum><cr><lf>

Format for NMEA 0183 Rev 4.10:

\$<TalkerID>RMC,<Timestamp>,<Status>,<Lat>,<N/S>,<Long>,<E/W>,<Speed>,<Trackgood>,<Date>,<MagVar>,<MagVarDir>,<mode>,<Nav_status><checksum><cr><lf>

Example for NMEA 0183 Rev 3.01 (Default):

\$GPRMC,183417.000,V,4814.040,N,01128.522,E,0.0,0.0,170907,0.0,W*6C

Example for NMEA 0183 Rev 4.10:

\$GNRMC,202340.000,A,4045.53297,N,01447.20361,E,0.2,0.0,291117,,,A,C*18

Field	Format	Description
-------	--------	-------------

\$	Char	Each NMEA message starts with '\$'
TalkerID	String, 2 characters	The talker ID (Fixed two characters). GP: If system works in GPS only mode GL: If system works in GLONASS only mode GA: If system works in Galileo only mode BD: If system works in BeiDou only mode QZ: If system works in QZSS only mode IR: If system works in IRNSS only mode GN: If system works in multi-constellation mode.
Timestamp	hhmmss.sss	UTC Time of GPS Sample: hh: hours (Fixed two digits) mm: minutes (Fixed two digits) ss: seconds (Fixed two digits) .sss: decimal fraction of seconds (Variable length) Note that decimal fraction assumes non zero values when the fix rate is bigger than 1Hz. Note that for Rev 4.10, this field is empty in case of invalid value.
Status	"A" or "V"	'V'=Invalid 'A'=Valid
Lat	DDMM.MMMMM	Latitude as degrees: DD: Degree (Fixed two digits) MM: Minutes (Fixed two digits) .MMMMM: Decimal fraction of minutes (Variable) Note that for Rev 4.10, this field is empty in case of invalid value.
N/S	"N" or "S"	Latitude direction: 'N'=North 'S'=South Note that for Rev 4.10, this field is empty in case of invalid value.
Long	DDDMM.MMMMM	Longitude as degrees: DDD: Degree (Fixed three digits) MM: Minutes (Fixed two digits) .MMMMM: Decimal fraction of minutes (Variable) Note that for Rev 4.10, this field is empty in case of invalid value.
E/W	"E" or "W"	Longitude direction: 'E'=East 'W'=West Note that for Rev 4.10, this field is empty in case of invalid value.

Speed	x.x, variable length field	Speed over ground in knots
Trackgood	x.x, variable length field	Course made good, max. 999.9
Date	Decimal, 6 digits	Date in format 'ddmmyy'
MagVar	Decimal, 4 digits	Magnetic variation in degree, not being output
MagVarDir	"E" or "W"	Magnetic variation "E" or "W" indicator, not being output
Mode	"D", "A", "N" or "E"	Positioning system Mode Indicator: "D" = Differential mode "A" = Autonomous mode "N" = data not valid "E" = Estimated (dead reckoning) mode
Nav_status	"S", "C", "U" or "V"	Navigational status indicator: "S" = Safe "C" = Caution "U" = Unsafe "V" = Not valid
*		End character of data field
Checksum		Hexadecimal checksum
<CR><LF>		Each of message

3.3.2. \$--VTG

Course over ground and ground speed, and this message provides the actual course and speed relative to ground.

Format for NMEA 0183 Rev 3.01(Default):

\$GPVTG,<TMGT>,T,<TMGM>,M,<SoGN>,N,<SoGK>,K,D*<checksum><cr><lf>

Format for NMEA 0183 Rev 4.10:

\$<TalkerID>VTG,<TMGT>,T,<TMGM>,M,<SoGN>,N,<SoGK>,K,D*<checksum><cr><lf>

Example:

\$GPVTG,73.2,T,,M,0.2,N,0.4,K,D*50

Field	Format	Description
\$	Char	Each NMEA message starts with '\$'
TalkerID	String, 2 characters	The talker ID (Fixed two characters). GP: If system works in GPS only mode GL: If system works in GLONASS only mode GA: If system works in Galileo only mode BD: If system works in BeiDou only mode

		QZ: If system works in QZSS only mode IR: If system works in IRNSS only mode GN: If system works in multi-constellation mode.
TMGT	ddd.d in degrees	Track in reference to "true" earth poles
T		Indicates "terrestrial"
TMGM	ddd.d in degrees	Track in reference to "magnetic" earth poles
M		Indicates "magnetic"
SoGN	ddd.d in knots	Speed over ground in knots
N		Indicates "knots"
SoGK	ddd.d in km/h	Speed over ground in kilometers per hour
K		Indicates "kilometres"
D	Char	Mode indicator: A = Autonomous mode D = Differential mode E = Estimated mode
*		End character of data field
Checksum		Hexadecimal checksum
<CR><LF>		Each of message

3.3.3. \$--GGA

Global positioning system fixed data.

Format for NMEA 0183 Rev 3.01(Default):

\$GPGGA,<Timestamp>,<Lat>,<N/S>,<Long>,<E/W>,<GPSQual>,<Sats>,<HDOP>,<Alt>,<AltVal>,<GeoSep>,<GeoVal>,<DGPSAge>,<DGPSRef>,<checksum><cr><lf>

Format for NMEA 0183 Rev 4.10:

\$<TalkerID>GGA,<Timestamp>,<Lat>,<N/S>,<Long>,<E/W>,<GPSQual>,<Sats>,<HDOP>,<Alt>,<AltVal>,<GeoSep>,<GeoVal>,<DGPSAge>,<DGPSRef>,<checksum><cr><lf>

Example:

\$GPGGA,183417.000,04814.03970,N,01128.52205,E,0,00,99.0,495.53,M,47.6,M,,*53

Field	Format	Description
\$	Char	Each NMEA message starts with '\$'
TalkerID	String, 2 characters	The talker ID (Fixed two characters). GP: If system works in GPS only mode

		GL: If system works in GLONASS only mode GA: If system works in Galileo only mode BD: If system works in BeiDou only mode QZ: If system works in QZSS only mode IR: If system works in IRNSS only mode GN: If system works in multi-constellation mode.
Timestamp	hhmmss.sss	UTC Time of GPS Sample: hh: hours (Fixed two digits) mm: minutes (Fixed two digits) ss: seconds (Fixed two digits) .sss: decimal fraction of seconds (Variable length) Note that decimal fraction assumes non zero values when the fix rate is bigger than 1Hz. Note that for Rev 4.10, this field is empty in case of invalid value.
Lat	DDMM.MMMMM	Latitude as degrees: DD: Degree (Fixed two digits) MM: Minutes (Fixed two digits) .MMMMM: Decimal fraction of minutes (Variable) Note that for Rev 4.10, this field is empty in case of invalid value.
N/S	"N" or "S"	Latitude direction: North or South Note that for Rev 4.10, this field is empty in case of invalid value
Long	DDDMM.MMMMM	Longitude as degrees: DDD: Degree (Fixed three digits) MM: Minutes (Fixed two digits) .MMMMM: Decimal fraction of minutes (Variable) Note that for Rev 4.10, this field is empty in case of invalid value.
E/W	"E" or "W"	Longitude direction: East or West Note that for Rev 4.10, this field is empty in case of invalid value.
GPSQual	Decimal, 1digit	0 = Fix not available or invalid 1 = GPS, SPS Mode, fix valid 2 = Differential GPS, SPS Mode, fix valid 6 = Estimated (dead reckoning) mode
Sats	Decimal, 2 digits	Satellites in use: example: 08
HDOP	x.x, variable length field	Horizontal dilution of precision, max: 99.0
Alt	x.x, variable length field	Height above mean sea level, max: 100000.0m

AltVal	"M"	Reference unit for altitude ("M" = meters)
GeoSep	x.x, variable length field	Geoidal separation measure in "M" = meters
DGPSAge	Empty	Not supported
DGPSRef	Empty	Not supported
*		End character of data field
Checksum		Hexadecimal checksum
<CR><LF>		Each of message

3.3.4. \$--GSA

GNSS DOP and active satellites. Satellites from different constellations are sent on separate messages. In case of multi-constellation mode, the talker ID is always GN. If NMEA is set as Rev 3.01, it is possible to force the talker ID as GN.

When NMEA is set as Rev 4.10, the talker ID could not be forced and is managed internally to be compliant with the standard. See parameter table for info about Talker ID available values.

Format for NMEA 0183 Rev 3.01(Default):

```
$--GSA,<Mode>,<CurrentMode>,<SatPRN1>,...,<SatPRNN>,<PDOP>,<HDOP>,<VDOP>,<checksum>
<cr><lf>
```

Format for NMEA 0183 Rev 4.10:

```
$<TalkerID>GSA,<Mode>,<CurrentMode>,<SatPRN1>,...,<SatPRNN>,<PDOP>,<HDOP>,<VDOP>,<Sy
stemID><checksum><cr><lf>
```

Example for NMEA 0183 Rev 3.01 (Default):

```
$GPGSA,A,3,05,21,07,24,30,16,12,,,,,,2.4,1.9,1.5*38
```

Example for NMEA 0183 Rev 4.10:

```
$GNGSA,A,3,23,03,22,09,01,19,17,06,31,11,,,1.1,0.6,0.9,1*3E
```

```
$GNGSA,A,3,67,66,81,65,88,75,82,74,,,,, 1.1,0.6,0.9,2*3D
```

```
$GNGSA,A,3,03,05,22,08,30,16,12,,,,,, 1.1,0.6,0.9,3*32
```

Field	Format	Description
\$	Char	Each NMEA message starts with '\$'
TalkerID	String, 2 characters	The talker ID (Fixed two characters). GP: If system works in GPS only mode GL: If system works in GLONASS only mode GA: If system works in Galileo only mode BD: If system works in BeiDou only mode QZ: If system works in QZSS only mode IR: If system works in IRNSS only mode

		GN: If system works in multi-constellation mode.
Mode	1 character	M = Manual, forced to operate in 2D or 3D mode A = Automatic, allowed to automatically switch 2D/3D
CurrentMode	Decimal, 1 digit	1 = Fix not available 2 = 2D 3 = 3D
SatPRN (1 to 12)	Decimal, 2 or 3 digits	Satellites list used for positioning
PDOP	x.x, variable length field	Position dilution of precision, max: 99.0
HDOP	x.x, variable length field	Horizontal dilution of precision, max: 99.0
VDOP	x.x, variable length field	Vertical dilution of precision, max: 99.0
SystemID	Hexadecimal, 1 digit	The system ID of this message: 1 = GPS 2 = GLONASS 3 = Galileo 4 = BeiDou 5 = QZSS 6 = IRNSS
*		End character of data field
Checksum		Hexadecimal checksum
<CR><LF>		Each of message

3.3.5. \$--GSV

GNSS satellites in view.

Usually GSV messages are organised per constellation and each message carries information about up to 4 satellites in view. Thus, in certain cases, to describe all the satellites in view from a constellation more than a message is needed. This set of message is printed once per each constellation with talker ID related to described constellation.

With NMEA Rev 4.10, the “GN” talker ID is forbidden in order to be compliant with the standard. Thus the module will print a set of messages for each constellation.

Format for NMEA 0183 Rev 3.01(Default):

```
$--GSV,<GSVAmount>,<GSVNumber>,<TotSats>,<Sat1PRN>,<Sat1Elev>,<Sat1Azim>,<Sat1CN0>,...,  
<Sat4PRN>,<Sat4Elev>,<Sat4Azim>,<Sat4CN0>,<checksum><cr><lf>
```

Format for NMEA 0183 Rev 4.10:

\$--GSV,<GSVAmount>,<GSVNumber>,<TotSats>,<Sat1PRN>,<Sat1Elev>,<Sat1Azim>,<Sat1CN0>,...,
<Sat4PRN>,<Sat4Elev>,<Sat4Azim>,<Sat4CN0>,<SignalID><checksum><cr><lf>

Example for NMEA 0183 Rev 3.01 (Default):

\$GPGSV,3,1,12,02,04,037,,05,27,125,44,06,78,051,23,07,83,021,30*7C

\$GPGSV,3,2,12,10,16,067,30,12,11,119,36,16,24,301,41,21,44,175,50*73

\$GPGSV,3,3,12,23,06,326,28,24,61,118,40,30,45,122,43,31,52,253,37*7C

Example for NMEA 0183 Rev 4.10:

\$GPGSV,3,1,09,30,68,039,49,05,61,266,50,28,52,137,47,07,38,052,48,01*5C

\$GPGSV,3,2,09,13,37,301,45,09,17,105,43,15,07,297,40,08,06,056,41,01*56

\$GPGSV,3,3,09,20,,,41,,,,,,,,,,01*5A

\$GLGSV,2,1,06,68,86,031,43,78,78,013,46,79,51,226,43,69,33,325,38,01*43

\$GLGSV,2,2,06,67,33,139,41,77,26,035,36,,,,,,01*46

\$GAGSV,2,1,05,08,76,129,44,02,65,057,46,30,56,205,45,07,48,311,44,06*4F

\$GAGSV,2,2,05,03,22,129,40,,,,,,06*7D

Field	Format	Description
\$	Char	Each NMEA message starts with '\$'
TalkerID	String, 2 characters	The talker ID (Fixed two characters). GP: If system works in GPS only mode GL: If system works in GLONASS only mode GA: If system works in Galileo only mode BD: If system works in BeiDou only mode QZ: If system works in QZSS only mode IR: If system works in IRNSS only mode GN: If system works in multi-constellation mode.
GSVAmount	Decimal, 1 digit	Total amount of GSV messages, max. 8
GSVNumber	Decimal, 1 digit	Continued GSV number of this message
TotSats	Decimal, 2 digits	Total number of satellites in view, max. 32
SatxPRN	Decimal, 2 digits	Satellites list used for positioning.
SatxElev	Decimal, 2 digits	Elevation of satellite x in degree, 0 - 90
SatxAzim	Decimal, 3 digits	Azimuth of satellite x in degree, ref. "North", 000 ... 359
SatxCN0	Decimal, 2 digits	Carrier to noise ratio for satellite x in dB, 00 ... 99
SignalID	Decimal, 1 digits	An identifier to indicate the signal in use. Currently it is 1 for GPS, GLONASS, 2 for BeiDou and QZSS 6 for Galileo
*		End character of data field
Checksum		Hexadecimal checksum

<CR><LF> Each of message

3.3.6. \$--GLL

Geographic positioning latitude/longitude.

Format for NMEA 0183 Rev 3.01(Default):

\$GPGLL,<Lat>,<N/S>,<Long>,<E/W>,<Timestamp>,<Status>,<mode indicator>,<checksum><cr><lf>

Format for NMEA 0183 Rev 4.10:

\$<TalkerID>GLL,<Lat>,<N/S>,<Long>,<E/W>,<Timestamp>,<Status>,<mode indicator>,<checksum><cr><lf>

Example:

\$GPGLL,4055.04673,N,01416.54941,E,110505.000,A,A*54

Field	Format	Description
\$	Char	Each NMEA message starts with '\$'
TalkerID	String, 2 characters	The talker ID (Fixed two characters). GP: If system works in GPS only mode GL: If system works in GLONASS only mode GA: If system works in Galileo only mode BD: If system works in BeiDou only mode QZ: If system works in QZSS only mode IR: If system works in IRNSS only mode GN: If system works in multi-constellation mode.
Lat	DDMM.MMMMM	Latitude as degrees: DD: Degree (Fixed two digits) MM: Minutes (Fixed two digits) .MMMMM: Decimal fraction of minutes (Variable) Note that for Rev 4.10, this field is empty in case of invalid value.
N / S	"N" or "S"	Latitude direction: north or south Note that for Rev 4.10, this field is empty in case of invalid value.
Long	DDDMM.MMMMM	Longitude as degrees: DDD: Degree (Fixed three digits) MM: Minutes (Fixed two digits) .MMMMM: Decimal fraction of minutes (Variable) Note that for Rev 4.10, this field is empty in case of invalid value.

E / W	"E" or "W"	Longitude direction: east or west Note that for Rev 4.10, this field is empty in case of invalid value.
Timestamp	hhmmss.sss	UTC time of GGL sample .sss" is the fraction of seconds; it assumes non zero values when the fix rate is bigger than 1Hz.
Status	"A" or "V"	Validity of data: "A" = valid, "V" = invalid
Mode indicator	"D", "A", "N" or "E"	Positioning system mode indicator: "D" = Differential mode "A" = Autonomous mode "N" = data not valid "E" = Estimated (dead reckoning) mode
*		End character of data field
Checksum		Hexadecimal checksum
<CR><LF>		Each of message

3.4. ST NMEA Messages Specification

3.4.1. \$PSTMANTENNASTATUS

The message reports the status of the antenna (working normally, open or short). It reports also information on antenna detection operating mode as well as the info on which antenna is active (if external or internal).

Synopsis:

```
$PSTMANTENNASTATUS,<status>,<op_mode>,<ext_ant>*<checksum><cr><lf>
```

Arguments:

Parameter	Format	Description
status	Decimal, 1 digit	Antenna status: 0 = Antenna NORMAL 1 = Antenna OPEN 2 = Antenna SHORT 3 = Anomalous behavior
op_mode	Decimal, 1 digit	Operating mode: 0 = Auto - the antenna is managed automatically by the software logic

		1 = Manual - the antenna ON-OFF or RF switching is controlled by commands
ext_ant	Decimal, 1 digit	0 = External antenna 1 = Internal antenna
checksum	Hexadecimal, 2 digits	Checksum of the message bytes without *<checksum><cr><lf> characters.

3.4.2. \$PSTMGEOFENCESTATUS

The message is sent from GNSS receiver to the host as response to **\$PSTMGEOFENCEREQ**. Geo-fence reports a bitmap against which circle is raising the alarm.

Synopsis:

```
$PSTMGEOFENCESTATUS,<timestamp>,<datestamp>,<status_1>,<status_2>,...,<status_x>*<checks
um><cr><lf>
```

Arguments:

Parameter	Format	Description
timestamp	Decimal, 6 digits	Hour (2 digits) Minute (2 digits) Seconds (2 digits)
datestamp	Decimal, 8 digits	Year (4 digits) Month (2 digits) Day (2 digits)
status_x	Decimal, 1 digit	Geo-fencing status for each circle where: 0 = Status unknown 1 = Current position is outside the circle 2 = Current position on circle boundary 3 = Current position is inside the circle
checksum	Hexadecimal, 2 digits	Checksum of the message bytes without *<checksum><cr><lf> characters.

3.4.3. \$PSTMODO

The message is sent from GNSS receiver to the host periodically if odometer subsystem is enabled and related messages are in the message list.

Synopsis:

```
$PSTMODO,<timestamp>,<date-stamp>,<odo-A>,<odo-B>,<odo-pon>*<checksum><cr><lf>
```

Arguments:

Parameter	Format	Description
timestamp	Decimal, 6 digits	Hour (2 digits) Minute (2 digits) Seconds (2 digits)
date-stamp	Decimal, 8 digits	Year (4 digits) Month (2 digits) Day (2 digits)
odo-A	Unsigned	Odometer A value
odo-B	Unsigned	Odometer B value
odo-pon	Unsigned	Odometer PON value
checksum	Hexadecimal, 2 digits	Checksum of the message bytes without *<checksum><cr><lf> characters.

4 Default Configurations

Table 3: Default Configurations

Item	Default
NMEA port baud rate	9600bps
Datum	WGS84
Rate of position fixing	1HZ
DGPS mode	Off
NMEA output messages	RMC, VTG, GGA, GSA, GSV and GLL

5 Appendix A References

Table 4: Related Documents

SN	Document Name	Remark
[1]	Quectel_L89_Hardware_Design	L89 Hardware Design
[2]	Quectel_L89_Reference_Design	L89 Reference Design

Table 5: Terms and Abbreviations

Abbreviation	Description
GPS	Global Navigation Satellite System
NMEA	National Marine Electronics Association
GGA	NMEA: Global Positioning System Fix Data
RMC	NMEA: Recommended Minimum Position Data
GSA	NMEA: GPS DOP and Active Satellites
GSV	NMEA: GPS Satellites in View
GLL	NMEA: Geographic Position – Latitude/Longitude
GLONASS	Global Navigation Satellite System (The Russian GNSS)
GNSS	Global Navigation Satellite System
VTG	NMEA: Track Made Good and Ground Speed
DGPS	Differential Global Positioning System
PDOP	Position Dilution of Precision
VDOP	Vertical Dilution of Precision
HDOP	Horizontal Dilution of Precision

PPS Pulse Per Second

UTC Universal Time Coordinated
